

*NOTE: "L" or "R" on Stations denote Left Bank or Right Bank location when looking downstream.

132+57 R

132+15 R

(NTS)

225

5

5

100

6.8

LOG/BOULDER STRUCTURE DETAIL

TYPE I BANK PROTECTION

(NTS)


File No. *BigSpCr_Details.dw*

7/30/15 9:20 AM

<u>Sheet</u> 12 of 21

5

1 2/3



BANK PROTECTION CONSTRUCTION NOTES

TYPE I BANK PROTECTION - LOG BOULDER

Materials.

- 1. Trees to be utilized for bank protection shall be Douglas Fir or Ponderosa Pine in sound condition and without substantial defects. Bole diameter at breast height (4.5 ft above ground level) will be 18 to 30 inches. Rootwads shall be at least 4 feet in diameter. The NRCS Inspector will approve the trees onsite prior to the commencement of hauling.
- 2. Header and Footer logs shall be 18 inches (+/- 6 inches) in diameter throughout their length.
- 3. It is the responsibility of the Contractor to harvest the trees, with rootwads and limbs largely intact, and deliver them to the project site without damage.
- Trees will be topped at a diameter of 8", and limbed, to produce material to be utilized for Type Il bank protection. Carefully stockpile limbs and tops at the project site to ensure full utilization of the material
- 5. Pinned connections will consist of 3/4" rebar, with a minimum length of 8" longer than the combined diameter of logs members to be connected.
- Boulders to be utilized for ballast will have a minimum weight of 2700 pounds each. Typical boulder size for this weight would be 3 to 3.5 foot median diameter where the least dimension is at least half of the maximum dimension.
- 7. Woven Erosion Control Fabric shall meet or exceed specifications for Belton GeoCoir 900.
- 8. Each Type I structure will require 3 willow clump transplants. Clumps will be 8' to 15' in height and approximate the width of the backhoe bucket. Refer to NRCS Idaho Technical Note 42, Willow Clump Plantings for details regarding harvest and transplanting.

Installation

- 9. The NRCS Inspector will stake locations of Type I bank protection structures.
- 10. Pin logs together as shown utilizing 3/4" rebar and a pneumatic post driver. Following placement of rebar, cut end off 8-12" above the top of the log, and bend over to be flush with log.
- 11. Place ballast boulders over logs, ensuring they are placed behind the header logs and in good contact with the lower logs.
- 12. Toe rock of the same gradation used in the Type II and III Bank Treatments shall be placed to a 4 foot horizonta thickness on the bank face around the rootwads, headers, and to within 2.5 feet of the floodplain surface.
- 13. Woven erosion control material shall be keyed a minimum of 3 feet between the soil fill and rock
- 14. Soil material shall be seeded in accordance with Riparian Area Seed/Planting Plan (MT 342 JS1) prior to placement of the woven erosion control fabric.

TYPE II BANK PROTECTION - WOODY TOE

- 1. The NRCS Inspector will stake the locations of Type II Bank Treatment.
- 2. Rock shall be be graded as shown and is the same gradation as used for Bank Treatments I and III.
- Woody toe material shall be comprised of limbs, tree tops, and brush meeting the size criteria noted above. Limbs, tops, root materials from trees utilized for Type I bank protection and on-site cleared woodys are acceptable.
- 4. Woody toe material shall be placed and pressed into place with a backhoe bucket to assure a dense compact section. Temporary weighting may be required to hold material in place while backfilling. Any weighting components shall be removed prior to bank completion.
- Coarse grained material of sufficient quantity shall be mixed/washed into the woody toe material to fill the voids. This quantity is ESTIMATED at 30% by volume of the space designated for woody material.
- 6. An 8" layer of graded toe rock shall be placed above the woody toe material prior to soil placement.
- 7. Woven erosion control fabric shall meet or exceed specifications for Belton Geocoir 900.
- 8. Woven erosion control fabric shall be keyed a minimum of 3 feet between the soil fill and rock material.
- 9. Soil material shall be seeded in accordance with Riparian Area Seeding/Planting Plan (MT 342-JS1) prior to placement of the woven erosion control fabric.
- 10. Vertical Dimensions are measured from thalweg elevations.

TYPE II BANK PROTECTION REACH LOCATION

DNSTREAM CL STA.*	UPSTREAM CL STA.*
102+25 L	102+91 L
107+20 R	107+84 R
108+60 R	109+15 R
110+30 R	110+54 R
111+54 R	112+10 R
112+80 L	113+42 L
116+10 L	116+64 L
117+59 L	118+19 L
119+20 R	119+61 R
120+60 R	121+20 R
123+70 R	124+10 R
127+49 L	127+79 L
129+80 L	130+72 L
131+52 L	132+02 L
132+57 R	132+82 R

*NOTE: "L" or "R" on Stations denote Left Bank or Right Bank location when looking downstream. α D

United States Department of Agriculture

File No. *BigSpCr_Details.dw*

STOF FISH

CREEK
S And N

PROTECTING CADAMS

BANK BIG IACHLER


MACHLE

RĘ


CTION


Д SP

7/30/15 9:20 AM Sheet *13* of *21*



N.T.S.





TYPE III BANK PROTECTION REACH LOCATION

DNSTREAM CL STA.*	UPSTREAM CL STA.*	
104+43 R	105+58 R	
105+87 L	106+98 L	
109+15 L	110+26 L	
121+20 L	122+35 L	
122+35 R	122+92 R	
123+03 R	123+17 R	
124+52 L	125+82 L	
128+05 R	129+58 R	

*NOTE: "L" or "R" on Stations denote Left Bank or Right Bank location when looking <u>downstream</u>.

227

CONSTRUCTION NOTES

- 1. The Engineer shall inspect and approve the rock toe prior to the construction of
- 2. Woven erosion control fabric shall be used for the outer fabric layer of the soil wraps. It shall meet or exceed specifications for Belton Geocoir 900. Non-woven erosion control fabric shall be used for the inner fabric layer and meet or exceed specifications for Tensar North American Green C125BN.
- 3. All Erosion Control Fabric shall be rolled out in the direction of streamflow. Overlap the ends of each blanket at least three (3) feet longitudinally from upstream to downstream.
- 4. A double layer of non-woven fabric shall be placed on top of the rock toe followed by 2" of soil and willow cuttings. An additional 2" of soil shall be placed over the willow cuttings before constructing the next soil lift.
- 5. The rounded end of the soil lift shall be reinforced with three (3) additional layers of the non-woven erosion control fabric. Reinforcement material may be folded and shall have a finished width of 3 feet. Place as shown on the drawings.
- 6. Sufficient slack shall be provided to allow for surface irregularities when placing the inner and outer layers of fabrics.
- 7. Anchor each soil lift in place with 2x4-inch by 24 inch long wedge stakes spaced 3 feet c−c.
- 8. overlap the fabric a minimum of 18" when fabric joining is needed. Stake each seam at 2 foot intervals or the manufacturer's recommendations, whichever is smaller.
- 9. Soil lifts and fill shall be seeded in accordance with Riparian Area Seed/Planting Plan (MT 342 JS1) prior to wrapping and covering with fabric.

ECTION CREEK S And N PROTEC SPRING C BANK P BIG SF MACHLER, States ment of Department of Agriculture United

Hoffm

 \varkappa 0

Designed

 \equiv

ш

Δ

Baker

Becker

:CT PARKS


PROJE(

ESTORATION FISH WILDLI

Re ŋ a

File No. *BigSpCr_Details.dw*

rawing No) 15-31 7/30/15 9:20 AM Sheet 14 of 21



TYPE IV BANK PROTECTION ROCK TOE DETAIL FOR RIFFLE SECTIONS N.T.S.
 Size
 % Passing


 9"
 100%

 6.75"
 60-100

 4.5"
 35-50

 2.25"
 10-35

 1.25"
 0-25



TYPE IV BANK PROTECTION

NEACH LOCATION					
DNSTREAM CL STA.*					
100+89 R	101+25 R				
101+95 R	102+25 R				
103+80 L	104+24 L				

*NOTE: "L" or "R" on Stations denote Left Bank or Right Bank location when looking <u>downstream</u>. BANK PROTECTION DETAILS — TYPE IV BIG SPRING CREEK RESTORATION PROJECT MACHLER, ADAMS AND MT FISH WILDLIFE & PARKS

K Hoffman K Hoffman

S. Becker

USDA United States
Department of Agriculture


File No. *BigSpCr_Details.dwg*

75-31 7/30/15 9:20 AM Sheet 15 of 21

RIFFLE BANK PROTECTION REACH LOCATION

DNSTREAM CL STA.*	UPSTREAM CL STA.*
102+25 R	102+75 R
103+95 R	104+43 R
104+24 L	104+65 L
105+70 L	105+87 L
105+58 R	106+05 R
106+98 L	107+70 L
109+15 R	110+30 R
112+10 R	113+10 R
112+10 L	112+80 L
114+83 L	116+09 L
115+00 R	116+29 R
118+20 L	119+20 L
118+20 R	119+20 R
121+20 R	122+35 R
124+10 R	124+70 R
124+10 L	124+50 L
125+82 L	126+73 L
126+00 R	126+49 R
127+79 R	128+05 R
127+79 L	128+60 L
129+58 R	130+57 R
131+67 R	132+15 R
132+82 L	133+02 L

*NOTE: Bank Treatment is the same on the left and right side of the stream.



* Soil material shall be seeded in accordance with Riparian Area Seed/Planting Plan (MT 342 JS1) prior to placement of the woven erosion control fabric.

TYPICAL SECTION (LEFT BANK)

RIFFLE

(NTS)

BANK PROTECTION DETAILS — RIFFLE BIG SPRING CREEK RESTORATION PROJECT MACHLER, ADAMS AND MT FISH WILDLIFE & PARKS

United States Department of Agriculture

Natural

File No. *BigSpCr_Details.dw*

7/30/15 9:20 AM

<u>Sheet 16 of 21</u>

Designed_K Hoffman


K Hoffman

S.Becker

TYPICAL CROSS-VANE PLAN VIEW

(NTS)


Set top of weir level with existing channel bottom at center (low point of Cross Vane)



TYPICAL CROSS-VANE ELEVATION VIEW

LOOKING DOWNSTREAM

(NTS)



TYPICAL CROSS-VANE CL PROFILE

(NTS)


CROSS VANE NOTES:

- 1) Boulders to be used for rock cross vanes on this project will be angular shot rock, of a generally rectangular shape. The source will be approved by the NRCS engineer prior to use as meeting project specifications.
- 2) Typical boulder dimensions will be approximately 5' x 3' x 3' for construction of the vane. Use a mixture of smaller sizes to fill voids between the boulders for the instream portion of the vane (no more than ~10% by volume of the structure). Smaller size rock may be used in the portion of the weir outside the constructed channel. The least dimension of any one boulder should not be less than 1/2 of the greatest dimension of the boulder. Óverall requirements:


Dmax = 7.0 ftD50* = 5.0Dmin = 3.0

*to be read as: at least 50% of boulders will have one dimension of at least 5 ft.

2) Vanes will be constructed with the NRCS Inspector present. Boulders will be placed by an excavator with careful attention to ensure they are stable and gaps are reduced to a minimum. Each boulder should bear against it's downstream neighbor so that the force of streamflow is transferred through the weir to the bank. As each boulder is placed, give a trial push in the downstream direction to ensure it will not tip under load.




TYPICAL COBBLE PATCH STRUCTURE PLAN VIEW



TYPICAL COBBLE PATCH STRUCTURE PLAN VIEW

GRADATION COBBLE PATCH ROCK



<u>% Passing</u> 100% 60-100

35-50 10-35 0-25

IN-STREAM STRUCTURE LOCATION CHART *NORTHING STRUCTURE CL STN *EASTING @ Ę Rock Cross Vane 103+35 17108479.63 2029573.28 Downstream Rock Cross Vane 133+36.7 17108565.73 2031566.65 Upstream

*NOTE: Easting and Northing coordinates reference the stream channel & Station of the Cross Vane Structures and the center profile of the Permanent Plugs on the right bank (looking downstream).

TYPICAL COBBLE PATCH STRUCTURE PLAN VIEW

COBBLE PATCH LOCATIONS					
Number	© Station	Number	© Station		
1	102+25	8	118+19		
2	103+95	9	121+20		
3	105+05	10	124+10		
4	107+10	11	125+99.5		
5	109+15	12	127+79		
6	112+10	13	129+80		
7	115+00				

United States Department of Agriculture

K Hoffmar

Jesigned.

Baker Becker

0

FRUCTURE DETAILS RESTORATION PROJECT MT FISH WILDLIFE & PARKS

-STREAM STRUCTURE SPRING CREEK RESTORATION RY, ADAMS AND MIT FISH WIL

BIG SF MACHLER,

 \leq

-ile No. BigSpCr_Details.dw

. Sheet *17* of *21*

